

Plan View

Description

The **Plan View** command is designed to revert the model space drawing back to a full plan view of the complete drawing with the **UCS** reset to **world**. It is generally used after the CAD-Duct **sectional view** command.


The **Plan View** command is accessed by one of the following methods:

From the toolbar **Select** 
At the **command line** enter **Planview**

Procedure

The sectional view command sets up '**clipping planes**' and rotates the UCS to suit the new view. It may not be convenient to use the AutoCAD® **Top View**, as clipping planes will still be active and the complete drawing will not be visible.

View using CAD-Duct **Sectional View** 



The CAD-Duct **Plan View** will return the drawing back to an overall plan view, the UCS will be returned to the world status and **all clipping planes will be removed**.

Plan View using CAD-Duct **Plan View** 